


BrightRidge®

REMOTE USER GUIDE

Broadband

Quick Reference Guide for the BrightRidge IPTV Kaon



TV Power
Powers on TV.

Menu
Launch Main Menu within the BrightRidge App with Live Video or last viewed On-Demand program.

Page (Up/Down)
Scroll page up or down in Guide or Menu screens.

Volume (Up/Down)
Increase or decrease volume levels.

Last
Displays the last 15 items watched.

Back/Exit
Return to previous Menu or state within current app. From Live Video, this button opens the BrightRidge App Main Menu.

Google Home
Launch AndroidTV Main Menu.

Shows
Launches the SHOWS playlist in the BrightRidge App.

Rewind
Pause/Play

Set
Set up the remote to control the TV and program an audio device.

TV Input
Changes video input on TV.

Power
Switch Kaon power ON, OFF, or STANDBY mode. Can also control TV power and audio system.

Live TV
Tune to the last content viewed in the BrightRidge App.

Mute
Mute audio.

Channel (Up/Down)
Select the previous and next available channels.

Guide
Launches the Channel Guide with BrightRidge App.

Arrows
Move to highlight items in respective direction.

Select/OK
Short Press: Confirms selection.
Long Press: Invokes the Search Menu in the BrightRidge App.

Movies
Launches the MOVIES playlist in the BrightRidge App.

Record
Fast Forward
Voice Search
Launches voice-based Google Assistant search.

0-9 Buttons
Enters channel numbers in the GUIDE or full screen video.

Use the BrightRidge App to access your IPTV service!

For more information, call BrightRidge Customer Service at (423) 952-5000 or visit www.mybightridge.com.



QUICK START

To begin enjoying your BrightRidge IPTV service, please follow these Quick Start instructions. For more assistance, please call (423) 952-5000.

1. Power on television on Kaon remote.
2. Access the Channel Guide by pressing the **Guide** button.
To exit, press **Back/Exit** twice.
3. Move around IPTV Environment with **Arrow** buttons and make selections with **Select/OK** button.
*To return to the BrightRidge Video App, select Menu, Live, Last, Guide, Shows, or Movies.

BRIGHTRIDGE IPTV FEATURES

Channel Guide

View other channels: Press up or down **Arrows** buttons to go lower or higher in the guide.

View other times: Press left or right **Arrows** buttons to go forward or return to current time.

Tune to a channel: Press **Select/OK** button to see program details.
Press **Select/OK** again to tune to program.

Restart

Restart allows you to start a program that is already in progress from the beginning.

From Play from the beginning pop-up: Press **Select/OK** button.

From a program: Press **Select/OK** button, use **Arrows** buttons to highlight **Restart**, press **Select/OK**.

Record

From the guide: Press **Record** button. If prompted, choose 'Record this episode only' or 'Record all episodes' based on preference.

From a program: Press **Record** button. If prompted, choose 'Record this episode only' or 'Record all episodes' based on preference.

Access Recording

Press **Menu** button, use **Arrows** to highlight Profile (left of Search) and press **Select/OK** button.

**Note: You can view your used recording space in the upper right corner*

Audio/Subtitle (Closed Caption)

Press **Select/OK** button, use **Arrows** buttons to highlight Audio. Subtitle, press **Select/OK**.

Access Replay TV

Open the Guide, find the desired channel, press **Left Arrow** to see and highlight Replay, and press **Select/OK** button.

Parental Controls

Press **Menu** button, use **Arrows** buttons to highlight Profile (left of Search), press **Select/OK**, use **Arrows** buttons to highlight Settings (gear in upper-right corner), press **Select/OK**, highlight Parental Controls, and press **Select/OK**.

Visit www.mybightridge.com for additional IPTV and Kaon information and user manuals.